



Расположение точек массирования на кузове

The diagram illustrates the locations of 20 massaging points (M1-M20) on a car body. The points are distributed as follows:

- Front Section:** M1 (left side), M2 (left side), M3 (left side), M4 (left side), M5 (left side), M6 (center), M7 (right side), M8 (right side), M9 (right side), M10 (right side), M11 (right side), M12 (center), M13 (center), M14 (center), M15 (right side), M16 (right side), M17 (right side).
- Side Section:** M18 (left side), M19 (left side), M20 (left side).

Примечание:

- Предвардители F1-F59 и реле K1-K20 расположены в монтажном блоке салона автомобиля
- предварители F60-F82 и реле K21-K30 расположены в монтажном блоке моторного отсека автомобиля
- Номера контактов разъемов изделий на схеме указаны для разъема изделия
- Шину CAN выполнить витой парой с шагом 40 мм (кроме ЭРА - 30 мм), сечение проводов - 0,5 кв.мм.
- Рекомендуемые длины отведений шины CAN не должны превышать 350 мм.
- * - витая пара с шагом 20 мм